

MARIO 14

How to Use & Precautions

The color plate can be attached or removed from the groove at the top of the wood body, where a magnet is integrated. Natural knots, uneven colors, and patterns on the wood surface are characteristic of natural materials. Both the bottom of the plate and the surface of the wood can be scratched or damaged if too much force is used, if the plates are attached and removed too often, or if there is any foreign substance present between them. Do not place items that may malfunction due to the magnet in the product.

자석이 내장되어 있는 우드 바디 상단의 오목한 홈에 컬러 플레이트를 결합하거나 분리할 수 있습니다. 나무 표면의 자연스러운 흠이, 균일하지 않은 색상과 패턴은 모양이 일정하지 않는 자연소재의 특징입니다. 플레이트 결합 시 무리한 힘을 주거나 지나치게 반복하여 탈착하거나 이물질이 있는 경우, 플레이트 하단과 나무 표면에 스크래치가 생기고 도장이 벗겨질 수 있습니다. 제품에 내장된 자석의 영향으로 고장 우려가 있는 소품을 올려두지 마시길 바랍니다.

